Trademarks

VIDA is a registered trademark of Fermax Asia Pacific Pte Ltd.. Contents subject to revision without prior notice.

All other trademarks remain the property of their owners.

Copyright Statement

Copyright © Fermax Asia Pacific Pte Ltd..

This publication may not be reproduced as a whole or in part, in any way whatsoever unless prior consent has been obtained from Fermax Asia Pacific Pte Ltd..

CE Mark Warning

These are Class A products. In a domestic environment these products may cause radio interference in which case the user will need to consider adequate preventative methods.

1. Checklist

The package should contain the following items:

- One set of VIDA Smart AC Controller
- This User's Guide

Please notify your sales representative immediately if any items are missing or damaged.



Fig. 1 Side View of VIDA Smart AC Controller

2. Overview

In the application of home automation, VIDA delivers a managed VIDA Smart AC Controller provided for IoT_based air conditioning services. This controller features SmartConfig capability, which allows you to easily turn on/off, adjust the temperature / fan speed / airflow direction, and set up the function mode as well as time schedule for the Mitsubishi air conditioners anytime and anywhere using the VIDA COOL APP we develop on smart phones.

Major Features:

- Compatible with WiFi client 2.4G IEEE 802.11 b/g/n
- Support SNTP simple network time protocol
- Support HTTP firmware upgrade
- Support DHCP client
- Support Watchdog Timer
- Support TCP server
- Support UART control
- Support SmartConfig function
- Support CN105 command protocol

3. Network Installation

The installation of VIDA Smart AC Controller is quite simple. Follow the steps described below to complete the network installation for VIDA Smart AC Controller.

- Make sure the WiFi function of your WiFi AP is enabled. (The connection procedure varies upon your router – refer to your router's manual for more information).
- Activate the WiFi function of your smart phone to connect with this WiFi AP wirelessly.
- Download the VIDA COOL APP from the iOS App Store/Android Google Play on your smart phones/tablets.

ACAUTION

To avoid causing the great damage to your air conditioner, please verify that the power of air conditioner in electric panel has been disconnected from the complete system before installing VIDA Smart AC Controller.



4. Button Description

BUTTON	FUNCTION	
Action Button	Press the Action Button of VIDA Smart AC Controller for more than 5 seconds to reset the system back to the factory default settings.	

5. LED Description

The VIDA Smart AC Controller real-time operational status can be monitored through a set of LED indicators located on the top panel.

LED	COLOR	FUNCTION
Status	Green	Lit when the device is powered on.
		Off when pressing the Action button for more than 5 seconds. And then release to reset (return to factory default settings) and restart the system, the LED indicator will be lit in green color.
	Green -→Yellow	Blinking in green and yellow colors by turns for 30 seconds when the device is upgrading the firmware.
WiFi		Slowly blinking when the device is not configured WiFi settings yet.
	Green	Rapidly blinking when the SmartConfig function is configuring.
		Lit when the SmartConfig function is completed.

6. Add Controller Using APP

Just follow the procedures listed below for step-by-step instructions to include VIDA Smart AC Controller into the WiFi network.

STEP1. Launch the VIDA COOL APP on your smart phone. Then, the following screen will be displayed.



- STEP2. Click the " icon on the screen to add a new Controller.
- STEP3. Click Add new devices if this Controller is added to your WiFi AP for the first time. (Or click Connected **devices** if this Controller had ever been added to your WiFi AP) The App will begin searching for this AP.
- STEP4. The SSID of your WiFi AP will be displayed on the screen when it is searched.
- STEP5. The system will request you to input the password of your WiFi AP for the connection with this AP. Click **OK** when you complete.
- STEP6. This Controller will be included (its WiFi LED blinks rapidly in green color at this time). If this Controller is included successfully, its WiFi LED will turn into steady green. Then, this Controller with the "+" icon will be listed on App.
- STEP7. Click this "+" icon to include this Controller into App.
- STEP8. Then, name this Controller and input its default account & password for your first-time login. Either choose the preferred Added Room or create a new room using the "+" icon next to the options of Master/Living/Dining/ Bed room if necessary. Click **Done** at the top-right corner of the screen when completing.

NOTE: By default, the Controller's default account is admin and no password is required.

- STEP9. The system will request you to change the password for the security when you login the system successfully. Click **OK** when you complete modifying the password.
- STEP10. This configured Controller with the "V" icon will be listed on the screen. Click OK to confirm the settings.
- STEP11. On the home page of App, the Controller you add will appear on the All tablet and/or the tablet of Master room/Living room/Dining room/Bed room/Other room upon the room you select/create in Step 8. (See

the figure below)

Note 1:



If the icon "O" of the specific Controller entry is in blue color, it represents this Controller is in on-line status; otherwise, it represents this Controller is in off-line status if the icon is in gray color

- STEP12. For the temperature/swing/FAN speed/function mode/time schedule settings of the air conditioner. please click the ">" icon belonging to this Controller entry to enter the setting page.
- STEP13. To remove this Controller from the App, please click Edit on the setting page. In the next page, you can choose Delete to remove the selected Controller directly or choose Delete & Reset to remove the selected Controller and reset it back to the factory default settings. Besides, you can modify the device name directly on this page.

7. Technical Specifications

Standards IEEE 802.3, 802.3u, 802.3x Network Interface Wi-Fi 802.11 b/a/n 1T1R Communication Console port (TTL level) Interface 2 Entries MAC Table SPI Flash: 2MB Memory SRAM: <50kB LEDs Status LED. WiFi LED Power DC 12V/5V by Air Conditioning cable Min. DC: 0.26W (12V/0.02A or **Power Consumption** 5V/0.05A) Max. DC: 0.45W (12V/0.04A or 5V/0.09A) 0.056ka Shipping Weight 70(W) x 44(D) x 16(H)mm Dimensions Operating: 0 ~ 50 °C Temperature Storage: -20 ~ 70 °C Humidity 5% ~ 95% RH non-condensing Certification CF * Please contact us for further reports and updates.

NOTE: Specifications may change without prior notice.

Contact Information

Fermax Asia Pacific Pte Ltd. 13 Lor 8 Toa Payoh, #07-12, Singapore 319261 TEL: +65 6259 0700 FAX: +65 6259 0070 www.fermax.com.sg l www.vidabyfermax.com

VIDA

VIDA Smart AC Controller

User's Guide

Version 1.1

Scan for list of compatible Mitsubishi Electric Air conditioner models

